Приложение IRC 08 F (версия 24.01.23 18:55)

Модели оригинальных пультов и соответствующие им коды пульта **IRC** приведены в разделе **"Коды пульта IRC 08 F"**.

Функции всех кнопок для каждого кода пульта **IRC** можно узнать из таблиц данного приложения.

Пульт **IRC** может иметь дополнительные функции (если указаны в столбце **"Доп. функция"**). Доступ к ним осуществляется при помощи кнопки **SHIFT** (см. в инструкции рис.1, п.16). Для доступа к дополнительным функциям нажмите кнопку **SHIFT** и, **удерживая её нажатой**, нажмите ту кнопку, дополнительная функция которой Вам необходима.

После первой установки батареек

Кнопка устройства пульта IRC	Код пульта IRC
TV	105
VCR	101
AUX	102
SAT	103

Кнопка устройства пульта IRC	Код пульта IRC
SHIFT + TV*	107
SHIFT + VCR*	108
SHIFT + AUX*	109
SHIFT + SAT*	208

*** Нажмите** кнопку **SHIFT** и, **удерживая её нажатой, нажмите и отпустите** одну из кнопок пульта: **TV**, **VCR**, **AUX** или **SAT**.

Доступные коды пульта IRC 08 F

Номер базы кодов (диапазон кодов)	Устройство базы кодов	Доступные коды пульта IRC
1 (101-199)	TV	101 - 117
2 (201-299)	VCR	201 - 211
3 (301-399)	AUX	301 - 325
4 (401-499)	-	Нет
5 (501-599)	TV	501 - 599
6 (601-699)	TV	601 - 699
7 (701-799)	TV	701 - 765
8 (801-899)	SAT	801 - 899
9 (901-999)	SAT	901 - 999

Коды пульта IRC 08 F

Коды к устройствам

Модель*	Устр-во	Код
C210CK (TV)	TV	101
C210CK (VCR)	VCR	211
C210EKX (TV)	TV	101
C210EKX (VCR)	VCR	211
CT-51E	TV	104
CT-54E	TV	104
CT-56	TV	104
CT-58	TV	104
CT-70FC (TV)	TV	101
CT-70FC (VCR)	VCR	211
CT-74FC (TV)	TV	101
CT-74FC (VCR)	VCR	211
CT-77FC (TV)	TV	101
CT-77FC (VCR)	VCR	211
CT-810ME	TV	108
KT1157-SX	TV	115
KT1157-SX-W	TV	115
LP20337-013	VCR	208
LP20878-002 (TV)	TV	112
LP20878-002 (VCR)	VCR	208
LP20878-008 (TV)	TV	112
LP20878-008 (VCR)	VCR	208
LP20878-018 (TV)	TV	112
LP20878-018 (VCR)	VCR	208
LP30451-001	VCR	208
LP30767-001	VCR	208
P6936451A	TV	110
PQ10181AE	VCR	201
PQ10344AE	VCR	208
PQ11202	TV	106
PQ11202H19	TV	106
PQ11374 (TV)	TV	105
PQ11374 (VCR)	VCR	208
RC-076 (DVD)	AUX, CD, DVD	301
RC-076 (TV)	TV	105
RC-076 (VCR)	VCR	208
RM-C1013	TV	105
RM-C1023	TV	105
RM-C110 (DVD)	AUX, CD, DVD	301
RM-C110 (TV)	TV	105
RM-C1100 (TV)	TV	105
RM-C1100 (VCR)	VCR	208
RM-C1120	TV	105
RM-C114 (DVD)	AUX, CD, DVD	301
RM-C114 (TV)	TV	105

Модель	Устр-во	Код
RM-C1150	TV	105
RM-C1171	TV	114
RM-C122	TV	114
RM-C1251G (DVD)	AUX, CD, DVD	301
RM-C1251G (TV)	TV	117
RM-C1257G (DVD)	AUX, CD, DVD	301
RM-C1257G (TV)	TV	117
RM-C1261	TV	105
RM-C1281	TV	105
RM-C1285	TV	105
RM-C1286	TV	105
RM-C1309	TV	105
RM-C1350	TV	105
RM-C1351	TV	105
RM-C1390	TV	105
RM-C1502	TV	105
RM-C1512B	TV	105
RM-C1808 (DVD)	AUX, CD, DVD	301
RM-C1808 (TV)	TV	105
RM-C1808 (VCR)	VCR	208
RM-C1816S (DVD)	AUX, CD, DVD	301
RM-C1816S (TV)	TV	111
RM-C1816S (VCR)	VCR	208
RM-C1830	TV	113
RM-C1855 (AUDIO)	AUX, CD, DVD	303
RM-C1855 (DVD)	AUX, CD, DVD	301
RM-C1855 (TV)	TV	114
RM-C1855 (VCR)	VCR	208
RM-C1861 (DVD)	AUX, CD, DVD	301
RM-C1861 (TV)	TV	114
RM-C1861 (VCR)	VCR	208
RM-C1897S (DVD)	AUX, CD, DVD	301
RM-C1897S (TV)	TV	111
RM-C1897S (VCR)	VCR	208
RM-C1932 (TV)	TV	111
RM-C214	TV	105
RM-C220	TV	105
RM-C223	TV	105
RM-C232	TV	105
RM-C237	TV	105
RM-C239	TV	105
RM-C3184	TV	116
RM-C333	TV	105
RM-C334	TV	105
RM-C355	TV	105

Модель	Устр-во	Код
RM-C360	TV	105
RM-C364	TV	105
RM-C407	TV	101
RM-C408	TV	109
RM-C408F	TV	101
RM-C410 (TV)	TV	101
RM-C410 (VCR)	VCR	211
RM-C430F	TV	101
RM-C438	TV	105
RM-C439	TV	105
RM-C440	TV	109
RM-C457	TV	105
RM-C461	TV	105
RM-C462	TV	105
RM-C463	TV	105
RM-C470	TV	102
RM-C482	TV	107
RM-C483	TV	107
RM-C485	TV	102
RM-C488	TV	107
RM-C490	TV	102
RM-C498	TV	105
RM-C530	TV	105
RM-C54 (DVD)	AUX, CD, DVD	301
RM-C54 (TV)	TV	105
RM-C54 (VCR)	VCR	208
RM-C548	TV	105
RM-C549	TV	105
RM-C565	TV	105
RM-C601 (TV)	TV	101
RM-C601 (VCR)	VCR	211
RM-C620F (TV)	TV	101
RM-C620F (VCR)	VCR	211
RM-C637	TV	105
RM-C680 (TV)	TV	101
RM-C680 (VCR)	VCR	211
RM-C683 (TV)	TV	102
RM-C683 (VCR)	VCR	209
RM-C696	TV	102
RM-C702 (TV)	TV	103
RM-C702 (VCR)	VCR	209
RM-C703 (TV)	TV	103
RM-C703 (VCR)	VCR	209
RM-C704 (TV)	TV	103
RM-C704 (VCR)	VCR	209

Модель	Устр-во	Код
RM-C707 (TV)	TV	103
RM-C707 (VCR)	VCR	209
RM-C711 (TV)	TV	103
RM-C711 (VCR)	VCR	209
RM-C712 (TV)	TV	103
RM-C712 (VCR)	VCR	209
RM-C795	TV	105
RM-C795 (VCR)	VCR	209
RM-C860B (TV)	TV	106
RM-C860B (VCR)	VCR	209
RM-C92	TV	105
RM-C993 (TV)	TV	112
RM-C993 (VCR)	VCR	203
RMP-720	TV	106
RMP-800	TV	106
RMP-880	TV	106
RMP-910	TV	106
RM-RK251	AUX, CD, DVD	317
RM-RK252	AUX, CD, DVD	319
RM-RK258	AUX, CD, DVD	316
RM-RX1003	AUX, CD, DVD	302
RM-RX270BK	AUX, CD, DVD	302
RM-RXC1001	AUX, CD, DVD	302
RM-RXQN1E	AUX, CD, DVD	302
RM-RXQW35	AUX, CD, DVD	302
RM-RXU1000	AUX, CD, DVD	302
RM-RXUV9RMD	AUX, CD, DVD	311
RM-SA1010U	AUX, CD, DVD	318
RM-SA911U	AUX, CD, DVD	318
RM-SDR011E (DVD)	AUX, CD, DVD	310
RM-SDR011E (TV)	TV	112
RM-SDR017E (DVD)	AUX, CD, DVD	310
RM-SDR017E (TV)	TV	112
RM-SDR019A (DVD)	AUX, CD, DVD	310
RM-SDR019A (TV)	TV	112
RM-SDR052E (DVD)	AUX, CD, DVD	310
RM-SDR052E (TV)	TV	112
RM-SDXU10U (AUDIO)	AUX, CD, DVD	315
RM-SDXU10U (TV)	TV	112
RM-SED302TXU (CD)	AUX, CD, DVD	303
RM-SED302TXU (DECK)	AUX, CD, DVD	304,305
RM-SED40TEU (CD)	AUX, CD, DVD	303
RM-SED40TEU (DECK)	AUX, CD, DVD	304,305
RM-SES30XU (CD)	AUX, CD, DVD	303
RM-SES30XU (DECK)	AUX, CD, DVD	304,305

* По каталогу «IRC»

Коды пульта IRC 08 F

Коды к устройствам

Модель	Устр-во	Код
RM-SES500U (CD)	AUX, CD, DVD	303
RM-SES500U (DECK)	AUX, CD, DVD	304,305
RM-SFSSD7R	AUX, CD, DVD	306
RM-SHXZ10R	AUX, CD, DVD	314
RM-SHXZ3R	AUX, CD, DVD	314
RM-SMXG500R	AUX, CD, DVD	312
RM-SMXJ100E	AUX, CD, DVD	313
RM-SMXJ10E (CD)	AUX, CD, DVD	303
RM-SMXJ10E (TAPE)	AUX, CD, DVD	304,305
RM-SMXJ30E	AUX, CD, DVD	307
RM-SMXJ555V	AUX, CD, DVD	308
RM-SMXJ750R	AUX, CD, DVD	314
RM-SMXK30R	AUX, CD, DVD	309
RM-SR212U (CD DISC)	AUX, CD, DVD	324
RM-SR212U (CD)	AUX, CD, DVD	323
RM-SRCBZ5E	AUX, CD, DVD	302
RM-STHM303U (AUDIO)	AUX, CD, DVD	320
RM-STHM303U (AUDIO+)	AUX, CD, DVD	321
RM-STHM303U (TV)	TV	112
RM-STHM303U (VCR)	VCR	203
RM-STHS1R (AUDIO)	AUX, CD, DVD	320
RM-STHS1R (AUDIO+)	AUX, CD, DVD	321
RM-STHS1R (FM/AM)	AUX, CD, DVD	325
RM-STHS1R (TV)	TV	112
RM-STHS1R (VCR)	VCR	203
RM-STHS33R (AUDIO)	AUX, CD, DVD	320
RM-STHS33R (TV)	TV	112
RM-STHS3R (AUDIO)	AUX, CD, DVD	320
RM-STHS3R (AUDIO+)	AUX, CD, DVD	321
RM-STHS3R (TV)	TV	112
RM-STHS3R (VCR)	VCR	203
RM-STHS5R (AUDIO)	AUX, CD, DVD	320
RM-STHS5R (AUDIO+)	AUX, CD, DVD	321
RM-STHS5R (TV)	TV	112
RM-STHS5R (VCR)	VCR	203
RM-SUXG38R	AUX, CD, DVD	322
RM-SXV034U	AUX, CD, DVD	301
RM-SXV042J (DVD)	AUX, CD, DVD	301
RM-SXV042J (TV)	TV	105
RM-SXV055U (DVD)	AUX, CD, DVD	301
RM-SXV055U (TV)	TV	105
RM-SXV057A	AUX, CD, DVD	301
RM-SXV058A	AUX, CD, DVD	301
RM-SXV065A (DVD)	AUX, CD, DVD	301
RM-SXV065A (TV)	TV	105

Модель	Устр-во	Код
RM-SXV069M	AUX, CD, DVD	301
RM-SXVFA95J (DVD)	AUX, CD, DVD	301
RM-SXVM555E	AUX, CD, DVD	301
SOME MODELS	VCR	202
SOME MODELS	VCR	203
SOME MODELS	VCR	204
SOME MODELS	VCR	205
SOME MODELS	VCR	206
SOME MODELS	VCR	207
SOME MODELS	VCR	210
UR64EC1623	VCR	208

Коды к TV устройствам различных марок

Марка	Код
AEG	544
AIWA	502, 503, 523, 528, 579, 634, 678, 706, 710, 712, 716
AKAI	501, 503, 512, 516, 520, 522, 524, 525, 537, 538, 540, 545, 546, 547, 550, 571, 572, 582, 583, 584, 585, 596, 598, 608, 613, 626, 652, 673, 691, 704, 708, 711, 722, 731
AKIR	511, 514, 516, 522, 524, 525, 537, 538, 541, 545, 547, 556, 577, 586, 594, 597, 598, 601, 623, 626, 629, 631, 649, 666, 680, 689, 690, 693, 699, 717, 739
AMCOL	501, 525, 545, 747
ANITECH	501, 525, 616, 726
ATLANT	501, 751
AVEST	537, 538, 539
BANG & OLUFSEN	728, 737
BBK	522, 551, 594, 597, 684, 701
BEKO	525, 530, 535, 559, 723, 742
BIGSTON	501, 503
BLAUPUNKT	512
BORK	525, 547, 646
BRAND	711
BROKSONIC	501
CAMERON	538, 550, 567, 675, 697, 702
CASIO	529, 705, 706
CASKA	761
CHANGHONG	516, 596, 642
CLATRONIC	501, 545, 559, 571, 742
CONTEC	501, 603, 604, 613
CORTLAND	644
CROWN	501, 503, 511, 524, 525, 530, 571
DAEWOO	501, 508, 518, 520, 525, 526, 536, 538, 539, 546, 565, 571, 576, 598, 613, 685, 687, 692
DARTLAND	501
DAYTRON	501
DEXP	516, 579, 596, 684, 702
DIGITAL	547
DISTAR	562, 616
DNS	596, 702, 708
DOFFLER	684, 708
DUAL	746
ELEKT	501, 503, 520, 525, 527, 615
ELEKTRONIKA	583
ELENBERG	538, 545, 550, 565, 567, 579, 581, 644, 655, 676, 683, 717
EPLUTUS	537, 644, 677, 682, 697, 724
ERC	537, 631, 764
ERISSON	511, 514, 516, 525, 526, 537, 538, 541, 550, 556, 561, 568, 586, 596, 599, 623, 626, 629, 631, 711, 712, 714, 739, 747
EVGO	538, 540, 630
FINLUX	501, 511, 583, 589, 608, 732, 758
FUJITSU	544, 573
FUNAI	501, 502, 503, 504, 505, 525, 537, 538, 581, 603, 764
FUSION	596, 642, 699, 705, 706
GBS	501, 520, 525, 571, 583
GENERAL	537, 556
GOLD STAR - LG	501, 512, 518, 525, 527, 559, 570, 583, 584, 589, 609, 613, 642, 706, 712, 742, 750, 765
GRUNDIG	501, 512, 525, 606, 662, 718, 719, 733
HAIER	518, 526, 561, 574, 657, 667, 669, 707
HAPPY	501
HARPER	706, 712
HCM	501, 503, 525
HELIX	701, 702, 708
HIL	503
HISENSE	525
HITACHI	501, 515, 518, 522, 525, 537, 544, 548, 554, 578, 584, 587, 588, 604, 613, 640, 729, 749
HORIZONT	525, 540, 545, 550, 559, 583, 664, 672
HPC	546
HYUNDAI	516, 518, 522, 525, 526, 537, 538, 540, 541, 546, 547, 550, 556, 580, 596, 597, 599, 626, 642, 648, 650, 655, 705, 711, 712, 714, 717, 760
INNO-HIT	501, 525, 571
IRBIS	596, 714
IVA (ИВА)	537, 561, 637
IZUMI	516, 537, 596, 663, 691, 695, 703, 705, 711
JINLIPU	537, 637
JVC	513, 515, 593, 604, 727
KAMACROWN	571
KANSAI	501, 525
KENSTAR	516
KITT	503, 613, 616, 726
KNEISSEL	753
KONK	537, 538, 560, 561, 581, 616, 626, 717
KRONMARK	596
LOEWE	542, 709, 744
MEDION	525
METZ	745
MITSUBISHI	501, 520, 522, 525, 604, 611, 722, 728, 744
MIYOT	537, 644, 656
MTC	501, 583
MULTITECH	501, 525
MYSTERY	516, 537, 597, 642, 650, 653, 701, 702, 708
NAD	518, 525
NASH	537
NEC	501, 517, 520, 526, 552, 604, 625, 722
NESCO	501, 525
NESONS	708
NOKIA	519, 584, 610, 614, 616, 740, 746
NOV	501, 616, 638
NOVEX	516, 546, 599
NTT	759
OMEGA	501, 571
ONIDA	513
ONIKS	516, 525, 537, 545, 546, 547, 680
ONWA	524, 525
OPER	644, 666, 682
ORBITA	635
ORION	501, 503, 506, 507, 509, 516, 525, 528, 537, 591, 603, 617, 619, 627, 641, 643, 664, 715, 720, 722, 729, 746
ORSON	526, 537

Коды к TV устройствам различных марок

Марка	Код
PANASONIC	512, 531, 532, 752
PHANTOM	644
PHILIPS	501, 511, 524, 525, 540, 549, 628, 639, 707, 748
PHOENIX	613
PHOENIX GOLD	708
PIONEER	548, 555, 566, 575, 647, 666
PIXELVIEW	525
PLANTRON	735
POLAR	525, 526, 537, 538, 540, 543, 546, 547, 581, 596, 599, 663, 664, 683, 703, 711, 717
POLAROID	525
PRESTIGIO	564, 656
PRIMA	522, 547
PROLOG	653, 655
RADUGA	525, 545, 569, 583, 743
RAINFORD	525, 537, 544, 545
RECOR	511, 525
REKORD	520, 525, 526, 537, 538, 539, 545, 547, 725, 736, 743, 747
RFT	535, 618, 728
ROADSTAR	501, 508, 525, 571
ROLSEN	503, 516, 525, 537, 538, 540, 543, 546, 564, 576, 592, 594, 596, 649, 656, 669, 684, 714
ROVERSCAN	662
ROYAL	501, 503, 525, 616
RUBIN	504, 516, 525, 537, 546, 583, 619, 665, 714
SABA	509, 510, 521, 602, 756
SALORA	584
SAMSUNG	501, 525, 526, 529, 563, 580, 595, 596, 608, 612, 613, 622, 641, 645, 688, 723, 741
SANSUI	524, 525, 538, 556, 695
SANYO	501, 519, 522, 525, 530, 540, 544, 550, 558, 604, 608, 610, 618, 621, 696, 722, 730, 734, 738
SATURN	702, 708
SCARLETT	541, 545
SCHNEIDER	525, 540, 571
SELECO	736, 763
SETRO	520
SHARP	526, 544, 548, 604, 707, 721
SHERION	616
SHIVAKI	501, 503, 508, 516, 518, 520, 525, 526, 527, 536, 538, 539, 540, 545, 546, 547, 550, 556, 580, 583, 585, 596, 599, 609, 619, 630, 632, 635, 636, 643, 644, 664, 681, 694, 708, 743
SIEMENS	512, 525, 660, 726, 734
SIESTA	501, 537, 637
SILELIS	613
SILVER	633
SITRONICS	503, 516, 525, 537, 538, 540, 543, 545, 594, 626, 629, 661, 671, 672, 674, 679, 680, 686
SOKOL	516, 525, 547, 635
SON	533, 604, 659, 722
SPEKTR	525, 538, 668
START	525, 537, 545, 546, 547
STASSFURT	535, 618
STINOL	525
SUPER	537, 561, 644, 653, 654, 655, 666, 677, 682, 724, 754
SUPER GENERAL	537
SUPR	501, 508, 516, 518, 520, 522, 525, 527, 529, 536, 537, 541, 563, 579, 580, 596, 597, 612, 642, 643, 687, 690, 705, 706, 712, 713
SUZUKI	516, 556
SVEN	574
TCL	521, 538, 540, 642
TEAC	525
TECHNICS	531, 537, 538
TECHNO	501, 525, 538, 544, 546, 556, 568, 579, 596, 599, 644, 664, 703
TECKTON	522, 582, 601, 669, 670
TELEFUNKEN	510, 521, 561, 590, 602, 605, 642, 708, 712, 714, 756, 757
TELEVISION	501, 525, 616
THOMSON	509, 510, 521, 550, 579, 602, 624, 642, 702, 756
TOSHIBA	516, 544, 553, 604, 651, 744
TRON	516, 525, 537, 538, 550, 574, 657
TVT	511, 525, 530, 535, 538, 583, 586, 620, 630, 723, 742
UNITED	525
VART	642
VESTEL	525, 544, 556, 583, 619
VIEWSONIC	557, 698
VIT	547
VITEK	537, 650
VITYAS	525, 708
VOLNA (ВОЛНА)	635
VR	516, 537, 565, 598, 702, 714
WALTHAM	503, 509, 511, 583, 584, 607, 613, 729, 762
XORO	522, 526, 545
XPX	663
НЕИЗВЕСТНАЯ МАРКА	525, 546, 574, 596, 648, 656, 666, 711, 755

Коды к SAT устройствам различных марок

Марка	Код
AIRTONE	968
ALFA GOLD	828
AMINO (СТРИМ)	829, 902
ARION	835
ARRIS	883, 963, 974
ASTON	811
BBK	931
BIG STAR	965
BIGSAT	839, 840, 903, 936
CADENA	958, 962
CONTINENT	886, 975
COSHIP	855
DAEWOO	872
D-COLOR	946, 961
DELTA SYSTEMS	985
DIGIFORS	946
DIVISAT	957, 958
D-LINK	923
DNS	950, 968
DR.HD	983
DRE	804, 888
DREAM	819
DUNE	927, 934
ECHOSPACE	862
ECHOSTAR	808, 809, 822
ELTEX	987
EPLUTUS	961
EUROSKY	840, 981
EUROSTAR	863
EUSTON	825
EVO	965
GALAXY INNOVATIONS (GI)	878, 881, 908, 911, 912, 917, 924
GENERAL SATELLITE	804, 868, 888, 907, 933, 954
GLOBALTEQ	833
GLOBO	909, 915, 925, 935, 945, 956, 971, 973, 995, 999
GOLD STAR - LG	871
GOLDEN INTERSTAR	821, 841, 879, 918
GOLDEN MEDI	847, 912
GOLDMASTER	911
HD BOX	847, 911
HITACHI	824, 832
HIVION	929
HOME	968
HOMECAST (ВОЛЯ)	820, 831, 836
HUAVEE	946
HUMAX	803, 804, 823, 848, 860, 861, 905, 949
HYUNDAI	968
ID DIGITAL	804
INTEK	984
INTERCROSS	988
INTRO	978
KAON	820, 949
KARTINA TV	934
KOSMOS	855, 856
LANS	970
LOCUS	946
LUMAX	852, 873, 907, 913, 965, 994
MAG	988
MEDIA COM	825
MOTOROL	883, 884, 901, 974
MYSTERY	910, 997
NDS	814
NEXT	864
NOKIA	813
NOT	941
ONLIME	905
OPENBOX	827, 835, 869, 870, 911, 990, 991
OPENTECH	972
OPENTEL	865
OPTICUM	971
ORBITA	946, 995
ORIEL	887, 926, 941, 948, 955, 986
PACE	801, 932, 953
PATIX DIGITAL	946, 967, 992
PAUXIS	842, 859
PERFEO	960, 981
PHILIPS	857, 899
PIONEER	851
POLAR	858
REFLECT	959
REXANT	977
RIKOR	916, 947
ROLSEN	930, 941, 942, 961
SAGEMCOM	906
SAMSUNG	803, 810, 812, 854
SEG	818
SELENGA	946
SEZAM	882
SKY VISION	952, 966, 977, 982
SKYMASTER	830
SKYWAY	911
SKYWORTH	989
STAR	833
STAR TRACK	826, 835, 943
STARNET	885
STRONG	805, 806, 815, 816, 817, 828, 830, 914
SUNNIWELL	875
SUPERBOX	903

Коды к SAT устройствам различных марок

Марка	Код
SUPERMAX	821, 866, 880, 924
SUPR	950, 960, 962
TECHNOSAT	852, 853
TEL-ANT	960
TELEFUNKEN	961, 968
TESLER	926
TOP BOX	965
TOPFIELD	837, 838, 877, 891
TOSHIBA	876
TV STAR	967
TVJET	946, 976
VESTEL	820, 824
VU+	919, 920, 921, 922
WORLD VISION	821, 928, 951, 952, 961, 968
XSAT	801, 807
XSAT (НТВ+)	801, 802, 807, 906, 972, 984, 998
YUXING	904
ZYXEL	874
АРБАКОМ	967
БИЛАЙН	883, 884, 901, 923
ВОЛГАТЕЛЕКОМ	842, 843, 844, 845, 846, 847, 849, 850, 858, 867
ДОМ.RU	820, 905
ДОМОЛИНК	874, 904
МТС	829, 855, 902, 964, 974, 979, 980, 989, 993
НЕИЗВЕСТНАЯ МАРКА	834, 835, 842, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 903, 904, 937, 938, 939, 940, 944, 945, 969, 971, 978, 996
РОСТЕЛЕКОМ	874, 904, 923, 963, 988, 993
СИГНАЛ	867, 968
ТВОЁ ТВ	820
ТЕЛЕКАРТА	867, 909, 973
ТЕЛЕЦИФРА	968

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 101		Код 102		Код 103		Код 104		Код 105	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD			S		TV				TV/AV/PC	
AUDIO ; NICAM			SOUND SYSTEM		BALANCE L	BALANCE R	N		SOUND SYSTEM	SURR.; L.SPAT.;
VIDEO ; SYS			P/S/N ; COL. SYS.		VIDEO 1		N		COLOUR SYSTEM	
; ZOOM			RED ; ZOOM		CANCEL DISPLAY				ZOOM	ECO SENSOR
▼ ; TV	TV		TV		TV				TV	
;			CH PRESET		MEMORY	MEMO STORE			PIP	STORE ; ;
; LOCK	NORM ; RESET		;	VSM ; STD	STANDARD VSM	RESET ;	; N		VSM STD	FREEZE ; ;
; FAV			EE						MODE ; F.T/L ;	STROBE
	POWER				; POWER				POWER ; /I	
AV	AV		; VIDEO		VIDEO 2 ; AV		TV/VIDEO		TV/VIDEO; AV; EXIT	
	MUTE				; MUTE		MUTE ;		MUTE; MUTING;	
MENU			; MENU ; OK		FUNCTION	POWER (VTR)			MENU ; OK	DVD MENU
EXIT									BACK	
▲	+		▲ ; MENU UP		BASS +		+		PIC.AD.▲;MENU ▲	
◄	-		- ; MENU-		LEVEL -		-		PIC.AD.- ;MENU-;◄	
OK			; MENU ; OK						OK	
►	+		+ ; MENU+		LEVEL +		+		PIC.AD.+;MENU+;►	
▼	-		▼ ; MENU DOWN		BASS -		-		PIC.AD.▼;MENU ▼	
; SETUP			VSM ; PIC. MODE		MODE				VSM ; PIC. MODE	PICTURE MODE
♪ ; TITLE					I-II				SOUND MODE	I-II
					TEXT	MIX			TV/TEXT/MIX ;	MULTI ;
GUIDE					BROWSE				PICTURE BOOSTER	AAC
	APM ; OFF TIMER		; OFF TIMER		APM ; TIMER OFF		TIME		SLEEP; OFF TIMER	AUTO VNR
	MPM ; ON TIMER		T/L ; F/T/L		MPM ; TIMER ON				POSITION	SWAP ;
RED ; ●			RED ; ZOOM		RED ; PAGE 1	● ; REC (VTR)	-		RED ; ZOOM	CH PRESET
GREEN ;			GREEN ;		GREEN ; PAGE 2		+		GREEN ; ; 3D	CHANNEL SCAN
YELLOW ;			YELLOW		YELLOW ; PAGE 3		-		YELLOW ;	HYPER BASS
BLUE ;			BLUE		BLUE ; PAGE 4		+		BLUE ; PICTURE	SOUND TURBO
	; ON SCREEN		; i		ON SCREEN	POSITION	DISPLAY		DISPLAY; ;	
	20+				DISPLAY VSM		P/C		RETURN+	
VOL -	VOL -				VOLUME -	TREBLE -	VOL - ;		VOLUME - ;	
VOL +	VOL +				VOLUME +	TREBLE +	VOL + ;		VOLUME + ;	
CH ⋁ ;	CH ▼		CHANNEL ▼		CHANNEL -	CHANNEL - (VTR)			CHANNEL - ; P ▼	SUB-P -
CH ⋀ ;	CH ▲		CHANNEL ▲		CHANNEL +	CHANNEL + (VTR)			CHANNEL + ; P ▲	SUB-P +
; SAT	10+		-/--		-/--		-/--		-/--	
CLEAR ; X					CH CC		11		CANCEL:; MULTI	
;	10				PAGE TIME	; REW (VTR)	12		S.PAG.;;▼;C.SYS	
▶ ; i	11		;		RESET ;	▶ ; PLAY (VTR)	13		INDEX ; ;	
; ?	12				REVEAL	; FWD (VTR)	14		REVEAL;;STROB.	NEXT
■ ;					HOLD	■ ; STOP (VTR)	15		HOLD; ; ▲;	
;					SIZE	; PAUSE (VTR)	16/AV		SIZE; ; NEXT;	
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 10		1, 2, ... 9, 0/AV	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 106		Код 107		Код 108		Код 109		Код 110	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD	SC3								AI	
AUDIO ; NICAM	I-II		SOUND THEATRE						CH I/II	
VIDEO ; SYS	P/S/N		VIDEO 2		VIDEO B		VIDEO		N R	
; ZOOM	16:9								EXCH	
▼ ; TV	T/L MODE		TV		TV		TV		CH	
;			S		VIDEO C				P in P	
; LOCK	;	VSM	EE		STD		RESET ; STANDARD		NORM; U-N-L;	
; FAV									))I((	
	POWER		POWER		POWER		POWER	(VTR)	I ; POWER	
AV	AV	S	VIDEO ; VIDEO 1		VIDEO A				TV/VIDEO	
	MUTE		MUTE		MUTE		MUTE		; MUTE	
MENU	MENU ;		MENU						MENU	
EXIT									RETURN ; SELECT	ESC
▲	▲	+	FUN ▲		BRIGHT +		BRIGHT +		▲	
◄	◄ ; -	-	FUN -		COLOUR -		CONTRAST -		◄	
OK									ENTER	
►	► ; +	+	FUN +		COLOUR +		CONTRAST +		►	
▼	▼	-	FUN ▼		BRIGHT -		BRIGHT -		▼	
; SETUP	VSM		COLOUR SYSTEM		NTSC ; G				PICTURE ; P.MODE	
♪ ; TITLE	♪		SOUND SYSTEM						SOUND ; S.MODE	
			VSM						PIP TV/AV; TV/TEXT	MIX
GUIDE	VNR								GAME	UNL
					OFF TIMER		TIMER OFF		TIMER	
							TIMER ON		SUB ; PCM/FM	
RED ; ●	RED				R		COLOUR -	● ; REC	RED	1*
GREEN ;	GREEN						COLOUR +		GREEN	2*
YELLOW ;	YELLOW	-					L BALANCE		YELLOW	3*
BLUE ;	BLUE	+					R BALANCE		BLUE	
			DISPLAY		ON SCREEN		SCREEN ON		RECALL	POS
	P/C								LST-CH ; STATUS	
VOL -			VOL -		VOLUME ▼		VOLUME -			- ; REVEAL
VOL +	+		VOL +		VOLUME ▲		VOLUME +			+ ; SUBCODE
CH ⋁ ;	P - ; ▼		CH ▼		CHANNEL ▼		CHANNEL -	CHANNEL - (VTR)	▼	PIP CH ▼
CH ⋀ ;	P + ; ▲		CH ▲		CHANNEL ▲		CHANNEL +	CHANNEL + (VTR)	▲	PIP CH ▲
; SAT			--		11		10+		0 ; -/--	
CLEAR ; X					12		20+		TIME ; CANCEL	
;							REW		+ ; SUBCODE	
▶ ; i	;						▶ PLAY		INDEX	
; ?							FF		- ; REVEAL	REVEAL
■ ;							■ ; STOP		HOLD	
;							; PAUSE / STILL		FREEZE	
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 10		1, 2, ... 9, 0		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 111		Код 112		Код 113		Код 114		Код 115	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD			VERTICAL POS. ▲				BASS			
AUDIO ; NICAM	I/II		SOUND SYSTEM	I/II			SOUND SYSTEM	I/II	AUDIO	
VIDEO ; SYS			COLOUR SYSTEM	COLOUR SYS. PIP			COLOUR SYSTEM			
; ZOOM	ZOOM		ZOOM CINEMA	FULL	ZOOM		ZOOM		ASPECT	
▼ ; TV	TV/DTV ; TV		VERTICAL POS. ▼				ECO		TV. RD	
;	; PC		PIP	STORE	;				PROG	
; LOCK	F.T/L		RESET	FREEZE PIP			F.T/L		S	
; FAV			ECO SENSOR						FAV	
	/I		POWER	POWER BASS	/I		POWER ; /I			
AV	AV		TV/VIDEO	SOURCE	TV/VIDEO		TV/VIDEO ; AV	TV/AV/PC	INPUT	
			MUTE				MUTING ;			
MENU	MENU		MENU		MENU		MENU	DVD MENU	MENU	
EXIT	BACK				BACK		BACK		EXIT	
▲	▲		▲ PICTURE/SOUND		▲ ; SUB-P ▲		▲		▲	
◄	◄		◄ PICTURE/SOUND		◄		◄		◄	
OK	OK				OK		OK		OK	
►	►		► PICTURE/SOUND		►		►		►	
▼	▼		▼ PICTURE/SOUND		▼ ; SUB-P ▼		▼		▼	
; SETUP			PICTURE MODE				PICTURE MODE	PICTURE MODE	P.MODE	
♪ ; TITLE	; ♪ ; GUIDE	♪ ; PC	SOUND MODE	SURROUND	♪		SOUND MODE	; ♪	S.MODE	
			TV/TXT/MIX	MODE			TEXT ;		TEXT	
GUIDE	; GUIDE		PROGRAMME ;	REGULAR			CINEMA SURR.;		GUIDE	
			OFF TIMER				TIMER ; SLEEP		SLEEP	
	;		THEATRE ; STATUS	CINEMA 1/2			PICTURE BOOSTER		LIST	
RED ; ●	RED ; ZOOM		RED	SWAP PIP	RED ; ZOOM		RED ; ZOOM		RED	●
GREEN ;	GREEN ;		GREEN	STROBE PIP	GREEN ; CINEMA		GREEN ;		GREEN	
YELLOW ;	YELLOW		YELLOW	PANORAMIC	YELLOW		YELLOW ;		YELLOW	
BLUE ;	BLUE		BLUE	LIVE ; X	BLUE		BLUE ; PICTURE		BLUE	
	●		DISPLAY	POSITION PIP	DISPLAY		DISPLAY ;		i	
	BACK		AUTO		RETURN+		RETURN+			
VOL -			VOLUME -		VOLUME -		VOLUME -; ◄;		VOL -	
VOL +			VOLUME +		VOLUME +		VOLUME +; ►;		VOL +	
CH ⋁ ;	P ▼		CHANNEL (PAGE) -		CHANNEL ▼		CHANNEL -; ▼; P ▼		CH -	
CH ⋀ ;	P ▲		CHANNEL (PAGE) +		CHANNEL ▲		CHANNEL+; ▲; P ▲		CH +	
; SAT			-/--	≥10			-/--		MIX	
CLEAR ; X	; I-II		CANCEL	10	; ♪				BACK	
; ●	;		SUB PAGE		F.T/L		; ▼			SUB.PAGE
; i	;		INDEX							INDEX
; ?	; TV/RADIO		REVEAL				;			REVEAL
;			HOLD		;		; ▲			HOLD
;	; GUIDE		SIZE		;					SIZE
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 116		Код 117	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD	NETFLIX			
AUDIO ; NICAM	LANG.			
VIDEO ; SYS				
; ZOOM			ASPECT	
▼ ; TV				
;	YouTube		TUNE	
; LOCK			C.C.	
; FAV				
			POWER	
AV			INPUT	
			MUTING	
MENU	MENU		MENU	
EXIT	EXIT		BACK ; EXIT	
▲	▲		CH + ; ▲	
◄	◄		VOL - ; ◄	
OK	OK		OK	
►	►		VOL + ; ►	
▼	▼		CH - ; ▼	
; SETUP	Q.MENU ;		VIDEO STATUS	
♪ ; TITLE	BACK		SOUND	
	TXT ;		THEATER PRO	
GUIDE	EPG ;			
			SLEEP TIMER	
	SUBT.		INDEX (MULTI SCR.)	
RED ; ●	RED	●	SELECT (MULTI SC.)	
GREEN ;	GREEN		REEZE (MULTI SC.)	
YELLOW ;	YELLOW		SWAP (MULTI SCR.)	
BLUE ;	BLUE		TWIN (MULTI SCR.)	
	i		DISPLAY	
			RETURN+	
VOL -	V -		VOL - ; ◄	
VOL +	V +		VOL + ; ►	
CH ⋁ ;	P ⋁		CH - ; ▼	
CH ⋀ ;	P ⋀		CH + ; ▲	
; SAT				
CLEAR ; X				
; ●				
; i				
; ?				
;				
;			_	
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 201		Код 202		Код 203		Код 204		Код 205	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD					SP/LP		SP/LP		_	
AUDIO ; NICAM					CONTR AUDIO		CONTR AUDIO		_	
VIDEO ; SYS					VTR CANC		VTR CANC		_	
; ZOOM	X2				SWAP EXCH.		SWAP EXCH.		_	
▼ ; TV					VPS VTV		VPS VTV		_	
;					MEMO COMPT.	MEMO COMPT.	MEMO COMPT.	MEMO COMPT.	_	
; LOCK	RESET				0000 COMPT.		0000 COMPT.		_	
; FAV			EJECT		EJECT ;		EJECT		EJECT	
	POWER		POWER		POWER ;		POWER		POWER	
AV	VCR		VT		TV/VCR		TV/VIDEO		VCR	
	OFF									
MENU	PROG		PROG		VHS PROG		VHS PROG		M	
EXIT					GO-TO A.DIR		GO-TO A.DIR		_	
▲					IMAGE +		IMAGE +			
◄					SELECT -		SELECT -		-	
OK	SELECT				SELECT		SELECT			
►					SELECT +		SELECT +		+	
▼					IMAGE -		IMAGE -			
; SETUP	ON				ON SCREEN		ON SCREEN		A	
; TITLE					DAILY ROT.		DISPLAY ERASE		B	
	SET	10-26			MODE DIGIT.		MODE DIGIT.		PROG	
GUIDE	A. DIR.	11-27			RECH		RECH		C	
	CLOCK	12-28			TIMER		TIMER		TIMER	
	CLOCK SET	13-29			ADAPT IMAGE		ADAPT IMAGE		D	
RED ; ●	REPEAT	● REC	RED ;	● REC	MARQ ; PRG MARK	● REC	MARQ ; PRG MARK	● REC	E	● REC
GREEN ;		14-30	GREEN ;	● ; (>)	SEARCH RECH.		SEARCH RECH.		F	
YELLOW ;	◄◄	15-31	YELLOW ; P		INDEX ⏮		INDEX ⏮			
BLUE ;	►►	16-32	BLUE ; VT		INDEX ⏭		INDEX ⏭			
	COUNTER				DISPLAY		DISPLAY		X2	
					P/C ; SOMMA.		P/C ; SOMMA.		P/C	
VOL -	▼ ; ◄◄				RECH ◄◄		RECH ◄◄		TRACK -	
VOL +	▲ ; ►►				RECH ►►		RECH ►►		TRACK +	
CH ⋁ ; ⏮	P -		P -		P -		P -		P -	
CH ⋀ ; ⏭	P +		P +		P +		P +		P +	
; SAT	-/--				-/-- ; INDEX		-/-- ; INDEX		-/--	
CLEAR ; X	CANCEL				DISPLAY ERASE		DAILY ROT.			
◄◄ ;	◄◄ (REW)		◄◄ (REW)		◄◄ (REW)		◄◄ (REW)		◄◄ (REW)	
► ; i	► (PLAY)		► (PLAY)		► (PLAY)		► (PLAY)		► (PLAY)	
►► ; ?	►► (F.FWD)		►► (F.FWD)		►► (F.FWD)		►► (F.FWD)		►► (F.FWD)	
■ ;	■ (STOP)	■	■ (STOP)		■ (STOP)		■ (STOP)		■ (STOP)	
❚❚ ;	❚❚ (PAUSE)		❚❚ (PAUSE)		❚❚ (PAUSE)		❚❚ (PAUSE)		❚❚ (PAUSE)	
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 206		Код 207		Код 208		Код 209		Код 210	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD					▲				I-HQ/PB	
AUDIO ; NICAM					I/II ; SP/EP				I-HQ	
VIDEO ; SYS					INDEX Plus +				AUTO TRACKING	
; ZOOM					TRACKING +				SHOW VIEW	
▼ ; TV					▼				TV/VCR	
;					C.MEMORY/ADD		M		VPT	
; LOCK					AUTO TRACK.				COUNTER RESET	
; FAV	EJECT		EJECT		TRACKING -		EJECT		EJECT ;	
	POWER		POWER		; POWER		POWER		POWER	
AV					TV/VCR		VCR		AV	
					AUDIO ;					
MENU	PROG		PROG		MENU ; PROG.				MENU	
EXIT									(-)	
▲					▲	▲			MULTI SPEED +	
◄					◄	◄			PICT. - ; STEADY ►	
OK					OK ; SELECT ; OSD	OSD ; ENTER			OK	
►					►	►			PICT. + ; STEADY ◄	
▼					▼	▼			MULTI SPEED -	
; SETUP									JOG SHUT	
; TITLE					TITLE				VERT.	
					INFO				TV TEXT	
GUIDE					PROG				PROG	
	TIMER		TIMER				TIMER		TIMER	
					?				PROG LIST	
RED ; ●		● REC		● REC		● REC		● REC	RED	● REC
GREEN ;									GREEN	
YELLOW ;						DATE -			YELLOW	
BLUE ;						DATE +			BLUE	SLOW ; STILL
					--:-- ; DISPLAY				DISPLAY	
	P/C		P/C		RE-VIEW				REPEAT	
VOL -	VOL -		VOL -		⏮ ; ◄	START DEBUT -	<<		◄ ; TRACKING ◄	
VOL +	VOL +		VOL +		⏭ ; ►	START DEBUT +	>>		► ; TRACKING ►	
CH ⋁ ; ⏮	P -		P -		PROG - ; ▼	STOP FIN -	P -		CH ▼	⏮
CH ⋀ ; ⏭	P +		P +		PROG + ; ▲	STOP FIN +	P +		CH ▲	⏭
; SAT	-/--		-/--		30 SEC ►►				SP/LP	
CLEAR ; X					X ; 0000 ; CANCEL				CANCEL (S/W)	
◄◄ ;	◄◄ (REW)		◄◄ (REW)		◄◄ ; ◄ ; REW		◄◄ (REW)		◄◄ ; REW	
► ; i	► (PLAY)		► (PLAY)		► ; ▲ ; PLAY		► (PLAY)		► ; PLAY	
►► ; ?	►► (F.FWD)		►► (F.FWD)		►► ; ► ; F.FWD		►► (F.FWD)		►► ; F.FWD	NEXT
■ ;	■ (STOP)		■ (STOP)		■ ; ▼ ; STOP		■ (STOP)		■ ; STOP	
❚❚ ;	❚❚ (PAUSE)		❚❚ (PAUSE)		❚❚ ; PAUSE		❚❚ (PAUSE)		❚❚ ; PAUSE	
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0				1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 211	
IRC 08 F	Функция	Доп. функция
▲ ; DVD		
AUDIO ; NICAM		
VIDEO ; SYS		
; ZOOM		
▼ ; TV		
;	⏻ ●○ M	
; LOCK		
⏏ ; FAV		
⏻	POWER	
AV	VCR	
🔇		
MENU		
EXIT		
▲		
◄		
OK		
►		
▼		
; SETUP		
♪ ; TITLE		
GUIDE		
	TIMER	
RED ; ●		● REC
GREEN ;		
YELLOW ;		
BLUE ;		
VOL -		
VOL +		
CH ⋁ ; ⏮	<<	
CH ⋀ ; ⏭	>>	
; SAT		
CLEAR ; X		
◀◀ ; ●	◀◀ (REW)	
▶ ; II	▶ (PLAY)	
▶▶ ; ?	▶▶ (F.FWD)	
■ ; ⧗	■ (STOP)	
▮▮ ;	▮▮ (PAUSE)	
1, 2, ... 9, 0		

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 301		Код 302		Код 303		Код 304		Код 305	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD	DVD/CARD		TUNING UP		TUNER		TUNER		TUNER	
AUDIO ; NICAM	AUDIO ; S.FREQ	3D PHONIC; SOUND	SOUND		FM MODE / MUTE	ACTIVE BASS EX.	SOUND EFFECT		SOUND EFFECT	
VIDEO ; SYS	SLIDE EFFECT		DIMMER		VIDEO		VIDEO		VIDEO	
; ZOOM	ZOOM		BASS BO.;AHB PRO		HALL					
▼ ; TV	DISC SELECT		TUNING DOWN		FM/AM ; TUNER		FM/AM ; TUNER		FM/AM ; TUNER	
;	PAGE	THEATER POS.;	AUTO PRESET		DOME		PRESET		PRESET	
; LOCK	STROBE		TONE		PRESET					
⏏ ; FAV	⏏ ; OPEN/CLOSE		OPEN / CLOSE ; ⏏		⏏ CD					
⏻	⏻/I ; STANDBY/ON	TV ⏻ / I	POWER (AC) ; ⏻/I		POWER ; ⏻/I	AUTO POWER OFF	POWER ; ⏻/I	AUTO POWER OFF	POWER ; ⏻/I	AUTO POWER OFF
AV	ANGLE; SLIDE EF.	TV/VIDEO	TAPE / AUX		AUX		AUX		AUX	
🔇	DIMMER				FADE MUTING	MUTE	FADE MUTING	MUTE	FADE MUTING	MUTE
MENU	MENU				PLAY MODE					
EXIT	RETURN				VOCAL MASKING					
▲	▲		BASS +		ROCK		OUT SPEAKER		OUT SPEAKER	
◄	◄	ZOOM -	TREBLE -		POPS					
OK	ENTER	ENTER			CLASSIC		AUTO SPEAKER		AUTO SPEAKER	
►	►	ZOOM +	TREBLE +		CAR					
▼	▼		BASS -		CINEMA		IN SPEAKER		IN SPEAKER	
; SETUP	CHOICE ; SET UP				AUTO SPEAKER					
♪ ; TITLE	TITLE ; TOP MENU	TITLE/GROUP	UNER/BAN.;FM/AM		SOUND MODE	SOUND EFFECT	SOUND MODE		SOUND MODE	
	PLAY MODE		PROGRAM		BGM		FM MODE / MUTE		FM MODE / MUTE	
GUIDE	DIGEST				PROGRAM		ECHO LEVEL		ECHO LEVEL	
	TIME ; DISPLAY		SLEEP		SLEEP ; WAKE UP		SLEEP ; WAKE UP		SLEEP ; WAKE UP	
	SUBTITLE		AUTO/MONO STER.		H.PHONE	D.CLUB				
RED ; ●	REPEAT		REPEAT		DISC 1	⏏ DISC 1	A (DECK)		A (DECK)	● ; REC PAUSE
GREEN ;	DISC 1		1-DISC CONTROL	⏏ 1-DISC CONTROL	DISC 2	⏏ DISC 2	B (DECK)		B (DECK)	
YELLOW ;	DISC 2		2-DISC CONTROL	⏏ 2-DISC CONTROL	DISC 3	⏏ DISC 3	ACTIVE BASS EX.		ACTIVE BASS EX.	
BLUE ;	DISC 3		3-DISC CONTROL	⏏ 3-DISC CONTROL	IN SPEAKER	OUT SPEAKER	VOCAL MASKING		VOCAL MASKING	
	DISPLAY	CHOICE ; ON SCR.	DISPLAY		ECHO LEVEL					
			RANDOM		SHIFT		SHIFT		SHIFT	
VOL -	AMP VOL +	TV VOL -	VOLUME -		VOLUME - ; VOL. ▼		VOLUME - ; VOL. ▼		VOLUME - ; VOL. ▼	
VOL +	AMP VOL -	TV VOL +	VOLUME +		VOLUME + ; VOL. ▲		VOLUME + ; VOL. ▲		VOLUME + ; VOL. ▲	
CH ⋁ ; ⏮	⏮ ; PREVIOUS	TV CH -	SEARCH TUN. ⏮		⏮ (CD)					
CH ⋀ ; ⏭	⏭ ; NEXT	TV CH +	SEARCH TUN. ⏭		⏭ (CD)					
; SAT	10	+10	10+		+10	10	+10		+10	
CLEAR ; X	✖ ; CANCEL		CONTINUE		CANCEL					
◀◀ ; ●	◀◀ ; SLOW -		SEARCH TUN. ⏮		⏮ (CD)		◀◀ (DECK A)		◀◀ (DECK B)	
▶ ; II	▶ ; SELECT		CD ▶/▮▮		▶/▮▮ (CD)		▶ (DECK A)	◀ (DECK A)	▶ (DECK B)	◀ (DECK B)
▶▶ ; ?	▶▶ ; SLOW +		SEARCH TUN. ⏭		⏭ (CD)		▶▶ (DECK A)		▶▶ (DECK B)	
■ ; ⧗	■ ; CLEAR		■ / CLEAR		■ (CD)		■ (DECK A)		■ (DECK B)	
▮▮ ;	▮▮ ; STROBE		CD ▶/▮▮		▶/▮▮ (CD)					
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 10		1, 2, ... 9, 10		1, 2, ... 9, 10	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 306		Код 307		Код 308		Код 309		Код 310	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD			CD 1		CD 1		CD 1		DVD	
AUDIO ; NICAM			ACTIVE BASS EX.		VOCAL MASKING		ACTIVE BASS EX.		AUDIO	
VIDEO ; SYS					V.INTRO		FM MODE		VHS	
; ZOOM	RANDOM				HIGHLIGHT		TAPE A/B		? ; HELP	
▼ ; TV			CD 2		CD 2		CD 2		HDD	
;	AUTO PRESET		CD 3		CD 3		CD 3		PROG. SCAN	
; LOCK	AHB PRO								ANGLE; LIVE	
⏏ ; FAV	⏏ CD								⏏ ; OPEN/CLOSE	
⏻	⏻/I		⏻/I		⏻/I		STANDBY/ON ; ⏻/I		⏻/I ; STANDBY/ON	
AV	MD/AUX		AUX		AUX		AUX		TV/VIDEO	
🔇	FADE MUTING		FADE MUTING		FADE MUTING		FADE MUTING			
MENU									MENU	MEMO/MARK
EXIT									RETURN	
▲	UP				# KEY CONTROL		SELECT +		▲	
◄	◄								◄	
OK	SET								ENTER	
►	►								►	
▼	DOWN				b KEY CONTROL		SELECT -		▼	
; SETUP	FM MODE		FM MODE		FM MODE		DISPLAY MODE		SET UP	
♪ ; TITLE	FM/AM		SOUND MODE		SOUND MODE		SOUND MODE		TOP MENU	LIVE
	DIMMER		FM/AM		FM/AM		FM/AM		PROGRAMME	
GUIDE	PROGRAM				ECHO		PROG./RANDOM		NAVIGATION	GUIDE
	SLEEP		SLEEP		SLEEP		SLEEP		VPS/PDC	VHS
	DOOR SLIDE				SUBTITLE		PTY/EON		SUBTITLE	
RED ; ●	REPEAT		TAPE A	REC PAUSE	TAPE A	REC PAUSE	REPEAT		DUBBING	● ; REC
GREEN ;	BASS		TAPE B		TAPE B				EDIT	REC MODE;
YELLOW ;	TREBLE									
BLUE ;	PTY/EON									
	DISPLAY				ON SCREEN				DISPLAY	INFO
	DISPLAY MODE				■ ;				ON SCREEN	
VOL -	VOLUME -		VOLUME -		VOLUME -		VOLUME -		JUMP -	
VOL +	VOLUME +		VOLUME +		VOLUME +		VOLUME +		JUMP +	
CH ⋁ ; ⏮	⏮		◀◀ / ⏮				◀◀ ; ⏮		CH/PR -	⏮ ; PREVIOUS
CH ⋀ ; ⏭	⏭		⏭ / ▶▶				▶▶ ; ⏭		CH/PR +	⏭ ; NEXT
; SAT			+10		+10		+10		REC LINK ; SAT	
CLEAR ; X	CANCEL								X ; CANCEL	
◀◀ ;	⏮		◀◀ / ⏮		◀◀ / ⏮ PREV		◀◀ ; ⏮		◀◀ ; SLOW -	
▶ ; i	▶/⏸ CD		▶/⏸ CD	◄ ► TAPE	▶/⏸ CD;SEL./STILL	◄ ► TAPE	▶/⏸ CD	► TAPE	▶ ; PLAY/SELECT	
▶▶ ; ?	⏭		⏭ / ▶▶		⏭ / ▶▶ NEXT		▶▶ ; ⏭		▶▶ ; SLOW +	
■ ;	■		■		■ ;		■		■ ; STOP/CLEAR	
⏸ ;	▶/⏸ CD		▶/⏸ CD		▶/⏸ CD;SEL./STILL		▶/⏸ CD		⏸ ; PAUSE	
1, 2, ... 9, 0			1, 2, ... 9, 10		1, 2, ... 9, 10		1, 2, ... 9, 10		1, 2, ... 9, 0 ; AUX	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 311		Код 312		Код 313		Код 314		Код 315	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD	TREBLE		DISC SKIP		DISC SKIP		◄ ► TAPE		DVD LEVEL	SURROUND MODE
AUDIO ; NICAM	BASS		SUBWOOFER		FM MODE		FM/AM		AUDIO/MPX	SOUND MODE
VIDEO ; SYS									ANGLE	
; ZOOM	AHB PRO						RANDOM		ZOOM	
▼ ; TV	TUNER BAND						◄ ► TAPE		CHANNEL LEVEL	
;	AUTO PRESET		TAPE A/B		TUNING MODE		TAPE A/B		VFP ; SCAN MODE	DIMMER
; LOCK									PAGE	
⏏ ; FAV	CD ⏏				⏏ CD				VARIO BASS	
⏻	⏻/I		⏻/I ; STANDBY/ON		⏻/I		⏻/I		⏻/I AUDIO	
AV	TAPE/AUX		AUX		AUX		AUX		FM/AM/AUX	
🔇			FADE MUTING		FADE MUTING		FADE MUTING		FADE MUTING	
MENU	CHARA				PROGRAM/SET		PROGRAM		MENU/PL	
EXIT	CANCEL						PROGRAM CANCEL		RETURN	
▲	UP		VOLUME +		VOL. +		SUBWOOFER +		▲	
◄	<		⏮/◀◀		⏮ ; ◀◀		SELECT -		◄	SUB. LEVEL -
OK	SET		■		FADE MUTING		PTY SEARCH		ENTER/SET	
►	>		⏭/▶▶		⏭ ; ▶▶		SELECT +		►	SUB. LEVEL +
▼	DOWN		VOLUME -		VOL. -		SUBWOOFER -		▼	
; SETUP	DIMMER						DISPLAY MODE		SET UP	KARAOKE SETTING
♪ ; TITLE	EDIT/TITLE		SOUND MODE		FM/AM		SOUND MODE		GROUP/TITLE	VOCAL SUPPORT
	PTY/EON						FM MODE		TOP MENU/PG	MIC MIX
GUIDE	PROGRAM						SOUND TURBO		KARAOKE	V.MASKING
	SLEEP		SLEEP		SLEEP		SLEEP		SLEEP	CLOCK/TIMER
	FM MODE		PTY/EON		TIMER ON/OFF		CD 5		SUB TITLE	RESERVE
RED ; ●	REPEAT		FM MODE		ACTIVE BASS EX.		CD 1	REC START/STOP	DISC 1	DISC 5
GREEN ;	RANDOM		FM/AM		SOUND MODE		CD 2		DISC 2	► USB MEMORY
YELLOW ;			SELECT -		TAPE A/B		CD 3		DISC 3	◄ ► TAPE-A
BLUE ;			SELECT +		► (TAPE)		CD 4		DISC 4	◄ ► TAPE-B
	DISPLAY		DISPLAY MODE				PTY/EON		ON SCREEN	DISPLAY
	DISPLAY MODE				REPEAT		REPEAT		REV. MODE	REPEAT
VOL -	VOLUME -		VOLUME -		VOL. -		VOLUME -		VOL - (AUDIO)	MIC VOL -
VOL +	VOLUME +		VOLUME +		VOL. +		VOLUME +		VOL + (AUDIO)	MIC VOL +
CH ⋁ ; ⏮	⏮		⏮/◀◀		⏮ ; ◀◀		◀◀ / ⏮		⏮ ; PREV	
CH ⋀ ; ⏭	⏭		⏭/▶▶		⏭ ; ▶▶		⏭ / ▶▶		⏭ ; NEXT	
; SAT			+10				+10		≥10	10
CLEAR ; X							BEEP ON/OFF		CANCEL	REPEAT A-B
◀◀ ;	⏮		⏮/◀◀		⏮ ; ◀◀		◀◀ / ⏮		◀◀ ; SLOW -	
▶ ; i	⏯ CD		▶/⏸ (CD)	► (TAPE)	⏯ (CD)		▶/⏸ CD		► DVD/CD	
▶▶ ; ?	⏭		⏭/▶▶		⏭ ; ▶▶		⏭ / ▶▶		▶▶ ; SLOW +	
■ ;	■		■		■		■		■	
⏸ ;	⏯ MD		▶/⏸ (CD)		⏯ (CD)		▶/⏸ CD		⏸ FM/PLAY MODE	
1, 2, ... 9, 0			1, 2, ... 9, 10				1, 2, ... 9, 10		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 316		Код 317		Код 318		Код 319		Код 320	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD	FM /▲		2nd VOL +		CD		▲		DVD	DBS
AUDIO ; NICAM			*/10 ;		DAT 1/TAPE 2		SURROUND		AUDIO	SURR. ; SURROUND
VIDEO ; SYS			#/12 ;		T1/D2 MON; T1►D1				VCR	SETTING
; ZOOM	ASPECT		ASPECT				ASPECT		ZOOM	
▼ ; TV	AM /▼		2nd VOL -		PHONO		▼		TV SOUND	
;			DUAL				DUAL		FM/AM	DIMMER
; LOCK			SURROUND						VFP ; SCAN MODE	ANGLE
; FAV									OPEN/CLOSE	
	SRC		/I/ATT				/I ; ATT		/I AUDIO	
AV	SRC		SOURCE				SOURCE		AUX ; TV SOUND	
			PHONE ;		MUTE ; FADE MUTE				MUTING	
MENU	ATT		AV MENU		CD		MENU		MENU; PTY	DISC 1
EXIT	ATT		■/ ; BAND/BACK		PHONO		RETURN		; REC	DISC 2
▲	FM /▲		▲	△ ; DISC+			△		▲	CENTER +
◄	⏮ /∨		◄ ; ⏮ ; ∨	◁			◁		◄	S.WFR -
OK	▶/⏸		ENT ; ▶/⏸	ENT			ENT		ENTER	DISC 5
►	⏭ /∧		► ; ⏭ ; ∧	▷			▷		►	S.WFR +
▼	AM /▼		▼	▽ ; DISC-			▽		▼	CENTER -
; SETUP	ANGLE		EQ		DAT 1/TAPE 2		SETUP		SET UP	DISC 3
♪ ; TITLE			TOP M		T1/D2 MON; T1►D1		TOP M		TITLE/GROUP	DISC 4
	ENT		DVD MENU				#		TOP MENU	KARAOKE ON/OFF
GUIDE			OSD						PLAY MODE	RESERVE
			ENT						SLEEP	ECHO
	CLR						OSD		SUBTITLE	VOCAL
RED ; ●			▽ ; DISC-		DIGITAL 1		; BAND/■		BASS/TREBLE	L SURR. -
GREEN ;			△ ; DISC+		DIGITAL 2		; PHONE		SPK-LEVEL	L SURR. +
YELLOW ;			◁		SPEAKERS 1		2nd VOL -		LEVEL -	R SURR. -
BLUE ;			▷		SPEAKERS 2		2nd VOL +		LEVEL +	R SURR. +
	DISP		DISP		DAT MONITOR		DISP		ON SCREEN; RDS	FL DISPLAY
	DIRECT		RETURN		D/A CON. DIRECT		RETURN		RETURN	PAGE
VOL -	VOL -		VOL -	2nd VOL -	MASTER LEVEL - ;		VOL -	2nd VOL -	AUDIO VOL -	TREBLE -
VOL +	VOL +		VOL +	2nd VOL +	MASTER LEVEL + ;		VOL +	2nd VOL +	AUDIO VOL +	TREBLE +
CH ∨ ; ⏮	⏮ /∨		◄ ; ⏮ ; ∨		MASTER LEVEL - ;		◄ ; ⏮ ; ∨		CHANNEL -	⏮ ; TUNING -
CH ∧ ; ⏭	⏭ /∧		► ; ⏭ ; ∧		MASTER LEVEL + ;		► ; ⏭ ; ∧		CHANNEL +	⏭ ; TUNING +
; SAT			*/10 ;				*		10	+10 ; 100+
CLEAR ; X	CLR		DIRECT ; CLEAR				DIRECT ; CLR		CANCEL	
◀◀ ;	⏮ /∨		◀◀				◀◀		◀◀ ; PTY - ; SLOW -	
▶ ; i	▶/⏸		ENT ; ▶/⏸				▶/⏸		▶ ; TA/NEWS/INFO	REPEAT
▶▶ ; ?	⏭ /∧		▶▶				▶▶		▶▶ ; PTY +; SLOW +	
■ ;			■/				; BAND/■		■ ; MEMORY	
⏸ ;	▶/⏸		▶/⏸				▶/⏸		⏸ ; FM MODE	A-B RPT
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		LINE 1,2,3		1, 2, ... 9, 0		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта	Код 321		Код 322		Код 323		Код 324		Код 325	
IRC 08 F	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲ ; DVD					CD		CD		DVD	DBS
AUDIO ; NICAM					TAPE1		TAPE1			SURR. ; SURROUND
VIDEO ; SYS					VIDEO SOUND		VIDEO SOUND		VCR	SETTING
; ZOOM					PHONO		PHONO			
▼ ; TV					FM		FM		TV SOUND	
;					AM		AM		MEMORY	DIMMER
; LOCK										
; FAV			▲							
			/I						/I AUDIO	
AV			FM/AM ; LINE						AUX ; TV SOUND	
			FADE MUTING		FADE MUTE		FADE MUTE		MUTING	
MENU	SETTING (v. 2.25.83)		SET						FM MODE	
EXIT			CANCEL							
▲			UP						PTY +	CENTER +
◄			⏮						TUNNING -	S.WFR -
OK	SETTING (ver 2.x.x)		PTY SEARCH ; ■						PTY SEARCH	
►			⏭						TUNNING +	S.WFR +
▼			DOWN						PTY -	CENTER -
; SETUP	S.SETUP (v.2.25.83)		DISPLAY/QP LINK							
♪ ; TITLE	DIMMER (v. 2.25.83)		BASS/TRE; AHB PR.		SURROUND		SURROUND		FM/AM	
			REPEAT; TA/NEWS.		CD		CD			
GUIDE			S.TURBO							
			SLEEP ; AUTO						SLEEP	
			CLOCK/TIMER		VIDEO SOUND		VIDEO SOUND			
RED ; ●					PHONO	● ⏸ (TAPE1)	PHONO	● ⏸ (TAPE1)	BASS/TREBLE	L SURR. -
GREEN ;			USB ; ▶/⏸		TAPE1		TAPE1		SPK-LEVEL	L SURR. +
YELLOW ;					FM		FM		LEVEL -	R SURR. -
BLUE ;			USB ; ▶/⏸		AM		AM		LEVEL +	R SURR. +
	DIMMER (ver 2.x.x)		DISPLAY/QP LINK						RDS DISPLAY	
	S.SETUP (ver 2.x.x)		MODE ; FM/PLAY						TA/NEWS/INFO	
VOL -			VOLUME -		VOLUME -		VOLUME -		AUDIO VOL -	TREBLE -
VOL +			VOLUME +		VOLUME +		VOLUME +		AUDIO VOL +	TREBLE +
CH ∨ ; ⏮			⏮		⏮ (CD)		⏮ (CD DISC)			
CH ∧ ; ⏭			⏭		⏭ (CD)		⏭ (CD DISC)			
; SAT					10+		10+		+10	
CLEAR ; X										
◀◀ ;			⏮		◀◀ (CD)	◀◀ (TAPE1)	◀◀ (CD DISC)	◀◀ (TAPE1)		
▶ ; i			CD ; ▶/⏸		▶ (CD)	▶ (TAPE1)	▶ (CD DISC)	▶ (TAPE1)		
▶▶ ; ?			⏭		▶▶ (CD)	▶▶ (TAPE1)	▶▶ (CD DISC)	▶▶ (TAPE1)		
■ ;			PTY SEARCH ; ■		■ (CD)	■ (TAPE1)	■ (CD DISC)	■ (TAPE1)		
⏸ ;			CD ; ▶/⏸		⏸ (CD)	⏸ (TAPE1)	⏸ (CD DISC)	⏸ (TAPE1)		
1, 2, ... 9, 0					1, 2, ... 9, 10		1, 2, ... 9, 10		1, 2, ... 9, 0	

Функции кнопок пульта IRC 08 F

Кнопки пульта IRC 08 F	Коды 501-765	
	Функция	Доп. функция
▲ ; DVD		
AUDIO ; NICAM		
VIDEO ; SYS		
; ZOOM		
▼ ; TV		
;		
; LOCK		
; FAV		
	POWER ;	
AV	TV/VIDEO ; TV/AV	
	MUTE ;	
MENU		
EXIT		
▲		
◄		
OK		
►		
▼		
; SETUP		
; TITLE		
GUIDE		
RED ;		
GREEN ;		
YELLOW ;		
BLUE ;		
VOL -	VOLUME ▼ ;	
VOL +	VOLUME ▲ ;	
CH ⋁ ;	CHANNEL ▼ ; P -	
CH ⋀ ;	CHANNEL ▲ ; P +	
; SAT		
CLEAR ; X		
;		
▶ ; i		
; ?		
■ ;		
;		
1, 2, ... 9, 0	1, 2, ... 9, 0	

Ссылка на таблицы функций кнопок баз кодов 8 и 9 (SAT, STB, DVB устройства) находится в разделе "Инструкции к пультам IRC" на сайте www.pult-irc.ru